
The logo for Laubjerg Vinsch AB is a horizontal rectangle divided into two equal halves. The left half is dark blue with the word "Laubjerg" in white, bold, sans-serif font. The right half is yellow with the words "Vinsch AB" in white, bold, sans-serif font, followed by a registered trademark symbol (®).

HYDRAULIC WINCH LV-HV200kN

Assembly & Operating Instructions

CONTENTS

INTRODUCTION	1
SAFETY WARNINGS AND PRECAUTIONS	1
WINCH WARNINGS AND PRECAUTIONS	2
UNPACKING	4
INSTALLATION	4
OPERATION	6
WINCH ACCESSORIES YOU WILL NEED	7
RIGGING TECHNIQUES	7
LUBRICATION	8
CABLE ASSEMBLY REPLACEMENT	8
TROUBLE SHOOTING	9
WINCH ASSEMBLY DRAWING	10
WINCH PARTS LIST	11
OUTLINE DIMENSIONAL DRAWING	13
Specifications	14

INTRODUCTION

Congratulations on your purchase of a highest class advanced powerful winch. We design and build winches to strict specifications and with proper use and maintenance should bring you years of satisfying service.

⚠ WARNING - Read, study and follow all instructions before operating this device. Failure to heed these instructions may result in personal injury and/or property damage.

Your winch can develop tremendous pulling forces and if used unsafely or improperly could result in property damage, serious injury or death. Throughout this manual you will find the following symbols for caution, warning and danger. Pay particular attention to the notes preceded by these symbols as they are written for your safety. Ultimately, safe operation of this device rests with you, the operator.



This indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. This notation is also used to alert you against unsafe practices.



This indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

SAFETY WARNINGS AND PRECAUTIONS

⚠ WARNING: When using the tool, basic safety precautions should always be followed to reduce the risk of personal injury and damage to the equipment. Read all this instructions before using this tool!

⚠ WARNING – Keep children away. Children must never be allowed in the work area Do not let them handle machines, tools, or extension cords.

⚠ WARNING – Store idle equipment. When not in use, tools must be stored in a dry location to inhibit rust. Always lock up tools and keep out of reach of children.

⚠ WARNING – Dress properly. Do not wear loose clothing or jewelry as they can be caught in moving parts. Protective, electrically non-conductive clothes and non-skid

footwear are recommended when working. Wear restrictive hair covering to contain long hair.

 **WARNING – Use eye and ear protection.** Always wear impact safety goggles. Wear a full face shield if you are producing metal filings or wood chips. Wear a dust mask or respirator when working around metal, wood, and chemical dusts and mists.

 **WARNING – Maintain tools with care.** Keep tools sharp and clean for better and safer performance. Follow instructions for lubricating and changing accessories. Inspect tool cords periodically and, if damaged, have them repaired by an authorized technician. The handles must be kept clean, dry, and free from oil and grease at all times.

 **WARNING – Disconnect switch.** Unplug switch when not in use.

 **WARNING – Stay alert.** Watch what you are doing, use common sense. Do not operate any tool when you are tired.

 **WARNING – Check for damaged parts.** Before using any tool, any part that appears damaged should be carefully checked to determine that it will operate properly and perform its intended function. Check for alignment and binding of moving parts; any broken parts or mounting fixtures; and any other condition that may affect proper operation. Any part that is damaged should be properly repaired or replaced by a qualified technician. Do not use the tool if any switch does not turn “On” and “Off” properly.

 **WARNING – Replacement parts and accessories.** When servicing, use only identical replacement parts. Use of any other parts will void the warranty. Only use accessories intended for use this tool.

 **WARNING – Do not operate tool if under the influence of alcohol or drugs.** Read warning labels on prescription to determine if your judgment or reflexes are impaired while taking drugs. If there is any doubt, do not operate the tool.

WINCH WARNINGS AND PRECAUTIONS

 **WARNING –** Keep hands and body away from Fairlead (cable intake slot) when operating.

 **WARNING** – Secure vehicle in position before using winch.

 **WARNING** – Be certain winch is properly bolted to a structure (or vehicle) that can hold the winch load.

 **WARNING** – Do not use inappropriate attachments to extend the length of the winch cable.

 **WARNING** – Never lift people or hoist loads over people.

 **WARNING** – Never come in between the winch and the load when operating.

 **WARNING** – Do not apply load to winch when cable is fully extended. Keep at least 5 full turns of cable on the spool.

 **WARNING** – After moving an item with the winch, secure the item. Do not rely on the winch to hold it for an extended period.

 **WARNING** – Examine winch before using. Components may be affected by exposure to chemicals, salts, and rust.

 **WARNING** – Never operate winch if cable shows any signs of weakening, such as knotting or kinking.

 **WARNING** – Do not cross over or under cable when the winch is under load.

 **WARNING** – Do not move your vehicle with the cable extended and attached to the load. You could easily exceed the winch rating and snap the cable.

 **WARNING** – Use gloves while handling cable.

 **WARNING** – When the vehicle is parked on an incline you should use wheel chocks.

 **WARNING** – Re-spool cable properly avoiding cable misalignment.

 **WARNING** – The winch cable must be wound onto the drum under a load of at least 10% of the rated line pull or the outer wraps will draw into inner wraps and damage winch cable

 **WARNING** – Before operating the winch under load you should check proper function of the winch by engaging and disengaging the clutch, by operating the directional controls, and operating the speed controls. This will ensure that the winch

is working properly and will help prevent unintended damage and injury. Cycling the winch prior to loading will also ensure the gears are properly aligned.

UNPACKING

When unpacking, check to make sure all parts are included. Refer to Assembly Drawings and Parts List (both with the like item numbers) at the end of this manual.

INSTALLATION

1. Your 40000lb winch is designed with a bolt pattern that is standard in this class of winch. Many winch mounting kits are available that utilize this bolt pattern for the most popular vehicle and mounting channels. If you will utilize the mounting channel you must ensure that it is mounted on a flat surface so that the three major sections (motor, drum and gear housing) are properly aligned. Proper alignment of the winch will allow even distribution of the full rated load.
2. Start by connecting the roller fairlead to the mounting channel using 2 each of the cap screw, flat washer, lock washer and securing with nut. (Make sure the screw is placed through the mounting channel and roller fairlead from inside the channel. This will allow enough clearance for the winch to be placed in the channel without obstruction.)
3. Mount winch to the vehicle using high strength cap screw. It should be aligned and secured to a solid part of the vehicle (front or rear) where the full rated load will be evenly distributed.
4. Please refer to installation illustration.

Mounting the Balance Valve:

The balance valve supplied is simply connected to motor. Be sure the balance valve's installing direction meets hydraulic principle chart. Otherwise, the winch will not reach the rated line pull, and it is also dangerous for winch to power off the cable with heavy load. If this symptom happens, simply disconnect the balance valve: exchange the oil hole between hydraulic motor and balance valve, while your winch is working in different direction, change $A \rightarrow C1, B \rightarrow C2$ into $A \rightarrow C2, B \rightarrow C1$. And reconnect it. If your


order demand the balance valve should be supplied, it will have been connected with the motor at the factory.

Plumbing Connections:

Keep all hoses away from any areas where heat may be considered too extreme such as an exhaust manifold or turbo. Lines should not be allowed to rub on any abrasive or vibrating surfaces. In some applications, 90° fittings on the directional valve and motor or balance valve are necessary to make hose mounting more flexible. After plumbing has been laid out on vehicle, install o-ring fittings supplied to valve. Torque tight. Do not over tighten any fittings. Install o-ring fittings on Winch Motor. Torque tight. Connect any hose port A on motor or port V1 on balance valve to port A on directional valve, port B on motor or port V2 on balance valve to port B on directional valve, port P on directional valve to pump's high pressure port, port T on valve to reservoir, if necessary Connect any hose port S on valve to steering box. Attach any o-ring or seal from vehicles original tube fitting to tube fitting.

Air actions clutch

- Air clutch for Free spool



WARNING

1. Clutch in all the time, when clutch out, need pressure 58~120psi into winch
2. Pressure should not below 58psi.
3. When winch is loaded and working, Do not clutch out.

⚠Caution:

The hydraulic system needs a relief valve to ensure the system safety. The absence of such a valve could cause serious injury and damage the winch.

If you are using a heat exchanger with your application to cool the hydraulic fluid you should refer to the illustration about mounting.

You should check the hydraulic fluid level and replace any that may have seeped out. The hydraulic system should be purged at this time. Listed below are the directions on how to purge the hydraulic system.

- 1) Start the engine.
- 2) Power the winch to draw out about 5 feet of cable.
- 3) Shut down the engine.
- 4) Check the fluid level and fill as needed.
- 5) Repeat steps 1 through 4 as necessary.
- 6) Start the engine.
- 7) Move the cable into the desired position.
- 8) Turn the wheels on the vehicle from the right lock to the left lock positions five times to help bleed the hydraulic system.
- 9) If the hand control unit is working backwards, simply exchange the brown and the white wire connections within the valve.

Test the winch for proper operation. Refer to the section below.

OPERATION

⚠WARNING

- 1 Make sure clutch is totally engaged before starting any winch operation;**
- 2 Stay clear and away from raised loads;**
- 3 Stay clear of cable while pulling do not try to guide cable;**
- 4 A min. of 4 wraps of cable around the drum barrel.**

General information:

The Winch's standard equipments contain gear reducer、 drum、 hydraulic motor、 solenoid valve. The winch obtains its pressure from the vehicle's existing power steering pump or other hydraulic power. The winch is totally sealed, can be used underwater.

There are several other ways to supply power to the winch. The first way is to use an individual pump for engineering use. The second way is to provide the winch's

hydraulic pressure is with the vehicle's exiting power steering pump (See Installation Instructions).

① Use a suitable individual pump, which doesn't have an oil pressure relief valve. It will supply pressure for both the steering box and the winch.

② Use a combined pump with an integrated oil valve. The oil valve will supply two kinds of flow based on the difference in demand. One type of flow will be constant and should be used with the steering system. The other will provide higher pressure and is for engineering use.

⚠ Caution:

Hydraulic system needs a relief valve to make sure the system is safe; if there is not relief valve in the system; it would be serious danger and the system can't operation. If your winch is driven by an existing hydraulic power system, the relief valve is also existing.

WINCH ACCESSORIES YOU WILL NEED


NOT INCLUDED WITH YOUR WINCH

Gloves – For handling the wire rope and hook strap.

Anchor Strap/Chain – Tree saver anchor straps are made of high quality nylon with high tensile strengths up to 15000lbs.


RIGGING TECHNIQUES

Self-Recovery



Locate a suitable anchor such as a strong tree trunk or boulder.

Always use a sling as an anchor point. **⚠ CAUTION** Do not attach the clevis hook back onto the cable as this could cause damage to the cable. As shown in Fig 3.1



⚠ CAUTION Do not winch from an acute angle as the wire rope will pile up on one side of the drum causing damage to wire rope and the winch. Fig 3.2

Short pulls from an angle can be used to straighten the vehicle. Long pulls should be done with the wire rope at a 90° angle to the winch/vehicle.




Fig 3.3

When pulling a heavy load, place a blanket or jacket over the wire rope five or six feet from the hook. In the event of a broken cable it will dampen the snap back. For additional protection open the hood of the vehicle as shown in Fig 3.3




Fig 3.4

For pulls over 70% rated line pull, we recommend the use of the snatch block/pulley block to double line the wire rope. Fig 3.4

This reduces the load on the winch and the strain on the rope by up to 50% depending on the included angle.




Fig 3.5

WARNING - Never use your winch for overhead hoisting or for lifting people or moving people.

LUBRICATION

1. All moving parts within the Winch having been Lubricated using high temperature lithium grease at the factory. No internal lubrication is required.
2. Lubricate Cable Assembly periodically using a light penetrating oil.

CABLE ASSEMBLY REPLACEMENT

If the wire rope has become worn or is beginning to show signs of strands breaking, it must be replaced before being used again.

1. Turning clutch to the “Free Spool” position.
2. Extend cable assembly to its full length. Note how the existing cable is connected to the drum.


3. Remove old cable assembly and attach new one as the Id cable connected to the drum. Insert the end of the new rope and secure the screw being tightly screwed
4. Retract cable assembly onto drum, first five wraps being careful not to allow kinking, then winch cable must be wound onto the drum under a load of at least 10% rated line pull.

⚠ WARNING - Only replace the wire rope with the identical replacement part recommended by the manufacturer.

TROUBLE SHOOTING

SYMPTOM	POSSIBLE CAUSE	SUGGESTED ACTION
Winch does not turn .	-Insufficiently hydraulic system pressure. -Improper connections of hydraulic system, no oil into motor.	-Check relief valve regulate pressure. -Check all the plumbing fixtures according to the working principle chart. -Defective directional control valve.
Motor runs but Cable drum does not turn	- The clutch is Not engaged	-Turn the clutch to the high or lows peed position. If problem still persists, a qualified technician needed to check and repair.
Winch drum runs slowly or without normal power.	-Insufficient pressure or oil flow -Insufficient fluid in the system - Wrong winch working direction.	-Bump is not suitable or defective. Change a new one or a suitable one -Check fluid level. Add fluid until full. -Change the connection of balance valve and motor.
Winch brake not working normally.	-Hydraulic pressure remnants in brake while winch stop. -Wrong winch working direction.	-Use bigger back oil pipe. -Change the connection of balance valve and motor.
Winch cannot spool off wire rope with load smoothly.	-Wrong winch working direction.	-Change the connection of balance valve and motor.

WINCH ASSEMBLY DRAWING



WINCH PARTS LIST

NO.	Part#	Description	Qty	Remark
1	GB5783-86	Bolt M8*20	6	
2	GB93-87	Gasket 8	6	
3	GB70.1-2000	Screw M12*55	4	
4	GB893.1-86	check ring 65	1	
5	GB3452.1-2005	O-ring 58*2.65	2	
6	IYJ100.1-1	Cylinder cover	1	ZL106
7	GB/T6172.1-2000	Nut M10	2	
8	GB3452.1-2005	O-ring 58*2.65	2	
9	IYJ100.1-2	Bib	1	ZL106
10	GB3452.1-2005	O-ring 58*2.65	1	
11	IYJ100.1-9B	Cylinder liner	1	ZL106
12	IYJ100.1-8	Air vat	1	HT200
13	IYJ150.4-2	Screw	1	
14	IYJ150.4-1	Fork	1	45
15	IYJ100.1-5	Spring seat	1	45
16	IYJ100.1-4	Spring	1	
17	IYJ150.4-3	linker	1	20CrMnTi
18	IYJ150-1	Gear ring	1	40Cr
19	IYJ150-17	First stage sun gear	1	20CrMnTi
20	IYJ150-14	Cover	2	PTFE
21	IYJ150.1-6	Cover	2	PTFE
22	IYJ150.1-5	Second stage sun gear	1	20CrMnTi
23	IYJ150-3	The left bearing	1	HT200
24	JB1001-77	Ventilate plug screw	2	
25	JB982-77	Gasket 20	2	
26	IYJ150-13	Driver axle	1	40Cr
27	IYJ150-12	Gasket	1	PTFE
28	IYJ150-11	The middle axle	1	40Cr
29	IYJ150-10	Gasket	1	PTFE
30	GB3452.1-85	Oil seal 32x52x8	1	
31	IYJ150-14	Gasket	1	PTFE
32	IYJ200-1	Drum	1	QT500-7
33	GB9877.1-86	Oil seal 200*230*15	1	
34	IYJ150-5	The right bearing	1	HT200
35	GB276-89	Bring 61938	1	
36	IYJ150-7	Gasket	1	45
37	GB70-85	Screw M10*20	8	
38	GB93-87	Gasket 10	13	
39	GB5783-86	Bolt M10*30	13	

40	IYJ200. 1-1	Motor seat	1	45
41	Z30A-16	Spring	16	
42	GB3452. 1-86	check ring A124*136*2	1	
43	GB3452. 1-86	O-ring 120*7	1	
44	IHKN3B21E. 1-2	Bib	1	45
45	GB70-85	Screw M10*30	12	
46	IYJ150. 3-2	Brake cage	1	45
47	IYJ200. 1-2	Splined hub	1	40Cr
48	HS70K-11	Inner friction disc	6	65Mn
49	HS70K-10A	outside friction disc	7	
50	IYJ150. 3-2	Bring seat	1	45
51	GB276-89	Bring 61916	1	
52	GB893. 1-86	check ring 75	1	
53	JB/ZQ4341-1997	check ring 102*4	1	
54	IYJ150. 3-1	Cover	1	Q235A
55	GB70-85	Screw M12*45	20	
56	GB5782-86	Bolt M12*100	12	
57	GB93-87	Gasket 12	12	
58	IYJ150-9	Driver axle	1	40Cr
59	GB9877. 1-86	Oil seal 130*160*12	1	
60	IYJ150-18	Driver axle	1	45
61	GB288-87	Bring 3053124	1	
62	IYJ150. 2. 1	Second stage planet carrier	1	
63	IYJ150. 1-4	First stage planet gasket	12	GCr15
64	GB309-84	Roller 5*21.8	252	
65	IYJ150. 2-3	Gasket	3	Cu
66	IYJ150. 2-2	Second stage planet gear	3	20CrMnTi
67	IYJ150. 1-1	First stage planet carrier	1	
68	IYJ150. 1-3	First stage planet gear	3	20CrMnTi
69	IYJ150. 1-2	First stage planet axle	3	GCr15
70	IYJ150. 1-1	Gasket	1	Nylon
71	IYJ150-15	Gasket	1	PTFE
72	IYJ150-16	Cover	1	HT200

Specifications

Layer of Cable		2	3	4	5
Rated Line Pull Per Layer	44000LBS [196KN]	37000LBS [164KN]	31000LBS [141KN]	28000LBS [124KN]	25000LBS [111KN]
Line Speed	23FPM [7.01m/min]	27.4FPM [8.35m/min]	31.78FPM [9.69m/min]	36.17FPM [11.03m/min]	40.57FPM [12.37m/min]

• Rated Torque	17000LBF-FT[21000 Nm]	• Rope Capacity	195 FT [40 m]
• Line Speed	23 FPM [7 m/min]	• Working Pressure	2465 PSI [17 MPa]
• Wire Diameter	1.01 IN [26.00 mm]	• Free Spooling	Available
• Design Standard	ISO 4301 & SAE J706	• Free Spooling Clutch	Pneumatic
• Hydraulic Motor	Sauer Danfoss OMT 310	• Oil	Industrial Gear Oil 220
• Rope Roller	Optional Item	• Oil Capacity	0.2 Gallon [0.8 Liter]
• Mounting Bolts	8×M24, Class 10.9	• Gross Weight	815 LBS [370kg]